



Instructions for updating the Actuator Description File (ADF)

Login to Accent at USER level with the password CENTORK
Navigate to TOOLS -> INSTALL ACTUATOR DEVICES



Locate the ADF files (ZIP format) and click Install



Once complete, the following message will be displayed:

